

## OSP Copper Cable Temperature Guidelines

OSP Copper Cable Normal Temperature Ranges <sup>1</sup>		
	°C	°F
Operation	-45 to +80	-49 to +176
Storage/Shipping	-45 to +80	-49 to +176
Installation <sup>2</sup>	-30 to +60	-22 to +140

<sup>1</sup>These temperature guidelines are applicable to traditional OSP copper designs manufactured to Telcordia and RUS standards as well as OSP Broadband designs. These guidelines are provided for convenience purposes only and do not replace or overrule individual cable performance specifications.

<sup>2</sup>OSP Copper cables may be installed at temperatures below 0°C (32°F), as low as -30°C (-22°F), if necessary. However, in such scenarios, best results will be obtained by conditioning the cable for 24 hours at or above 18°C (65°F) prior to installation.